

Electric CHANGEdesk

■ OPERATING INSTRUCTIONS:

IMPORTANT: Before using your **Electric CHANGEdesk**:

- 1** Read and clearly understand the contents of this manual
- 2** Understand how to adjust **Electric CHANGEdesk** correctly
- 3** Practice adjusting **Electric CHANGEdesk** with nothing on it.

Electric CHANGEdesk requires no installation and simple assembly of the ergonomic keyboard tray. **Electric CHANGEdesk** is designed to hold single & dual monitors, iMacs, laptops, and other similar devices at a comfortable height for sitting or standing at a desk. The max load is 30lbs.


IMPORTANT: BEFORE placing a computer, monitor, or other device on **Electric CHANGEdesk**, practice adjusting **Electric CHANGEdesk**'s height.

Have Questions? Need Help?

Our A+ customer support team is here to help:

EMAIL: hello@UncagedErgonomics.com

PHONE: 240-583-0517



1. Place **CHANGEdesk** on top of any level desk, table, or counter. Connect one end of the power cord to **CHANGEdesk** and the other end to an electrical outlet.

2. Press the UP Arrow to raise **CHANGEdesk**. Later, use the Up/Down arrows to Raise/Lower **CHANGEdesk**

3. Use 1 screw to connect the Keyboard Tray Bracket to the left side of the middle level. Then use 1 screw to connect the second Keyboard Tray Bracket to the right side of the middle level.

4. Use 2 screws to secure the right side of the Keyboard Tray to the Right Keyboard Tray Bracket. Repeat for the Left side.

5. To adjust the keyboard tray's height and angle:
a. Release the levers on the right and left side of the keyboard tray.
b. Raise and tilt the keyboard tray to your desired position.
c. Lock the levers on the right and left side of the keyboard tray.

WARNING! Only adjust **Electric CHANGEdesk** when nothing is on the bottom and middle shelves.

WARNING! PINCH POINT!: Do not place fingers or extremities near or inside the "X-shaped" joints.

DANGER! PINCH POINT!: Do not let fingers or extremities cross the vertical plane created by the X-shaped joints.

TIPS:

1. The top panel is smooth and ideal for writing.
2. When standing, the middle level is a convenient shelf for storage, organization & writing.
3. The hole on the left side of the base is for cable management.